CALEXOTICS®

SE-0077-53-3

LOCK-N-PLAY™ WRISTBAND REMOTE PANTY TEASER



FEATURES:

- Compact and discreet waterproof wristband remote control - use alone or with a partner
- Perfect placement every time with magnetic tab wings that attach securely on panty
- 12 intense functions of vibration, pulsation and escalation
- Waterproof stimulator may be used independently of remote
- State-of-the-art memory chip resumes on last function used
- Perfectly contoured with added ridges
- Instructions included
- Easy push-button control
- Extended 32.75'/10 m range
- RED certificate included
- USB rechargeable (stimulator and remote) – dual charging cord included
- Complete charge in 50 minutes
- Runs for 55 minutes on high speed and 90 minutes on low speed



MATERIALS: Silicone (stimulator, controller) ABS with Silver Plating (magnetic backing) Stainless Steel (clasp)

MEASUREMENTS:

3.75" x 1"/9.5 cm x 2.5 cm
Wristband adjusts up to 9.25"/23.5 cm

CHARGING INFORMATION:

The stimulator must be activated to pair with the remote. A flashing LED light will indicate the stimulator is activated. Ensure the stimulator is deactivated after each use to preserve battery life. Stimulator will automatically deactivate after 30 minutes of inactivity. Product has a memory chip feature and will resume on the last function used. LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 50 minutes; Run time on high: 55 minutes; Run time on low: 90 minutes.

OPERATING INSTRUCTIONS:

To use stimulator independently:

1. Press and hold the button on the stimulator for 3 seconds to activate; a flashing LED light will indicate the stimulator is activated.
2. Press the button to turn on vibrations.
3. Press the button repeatedly until the desired function is reached.
4. To turn off vibrations and deactivate stimulator, press and hold the button for 3 seconds. The LED will turn off.

To use with remote wristband:

1. Press and hold the button on the stimulator for 3 seconds to activate; a flashing LED light will indicate the stimulator is activated.
2. Using the remote wristband, press the power button once to turn on vibrations.
3. Press the function button on the remote wristband repeatedly until the desired function is reached.
4. To turn off vibrations, press the power button on the remote wristband.
5. To deactivate, press and hold button on the stimulator for 3 seconds.