
CALEXOTICS®

SE-4412-35-3

HYPE™ DUAL WAND



FEATURES:

- Ergonomically curved, premium Silicone dual action massager
- Dual motors with 10 functions of vibration, pulsation and escalation
- Flexible shaft moves with you
- Easy push-button control with LED lights
- Security travel lock feature - hold for 3 seconds to turn on or off
- USB rechargeable - charging cord included

10 SILICONE WATER PROOF Dual Motors USB RECHARGEABLE

MATERIALS: Silicone (massager), ABS with PU Cote (controller), ABS with Metallic Plating (décor), Nickel-Free Copper (charging port)

MEASUREMENTS:

4.5" x 1.25"/11.5 cm x 3.25 cm (shaft)
1.75" x .75"/4.5 cm x 2 cm (stimulator)

OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the top button for 3 seconds.
2. Press the bottom button repeatedly until the desired function is reached.
3. To turn product off, repeat step 1.

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2 hours; Run time on high: 60 minutes; Run time on low: 2 hours.

CALEXOTICS®

SE-4412-20-3

HYPE™ FLEXI-WAND



FEATURES:

- Super slim vibrating Silicone massager with contoured tip
- Discreetly designed to enhance intimacy
- 10 functions of vibration, pulsation and escalation
- Flexes and bends for multi-directional positioning
- Easy push-button control with LED lights
- Security travel lock feature - hold for 3 seconds to turn on or off
- USB rechargeable - charging cord included



MATERIALS: Silicone (massager) ABS with Metallic Plating (décor)

MEASUREMENTS:

5.5” x 1”/14 cm x 2.5 cm

OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the top button for 3 seconds.
2. Press the bottom button repeatedly until the desired function is reached.
3. To turn product off, repeat step 1.

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 1 hour; Run time on high: 30 minutes; Run time on low: 45 minutes.

CALEXOTICS®

SE-4412-50-3

HYPE™ MASSAGER



FEATURES:

- Vibrating personal massager to increase circulation
- 10 functions of vibration, pulsation and escalation
- Ultra powerful head with resonating vibrations and flexible neck
- Easy push-button control with LED lights
- Security travel lock feature - hold for 3 seconds to turn on or off
- USB rechargeable - charging cord included

10 SILICONE WATER PROOF USB RECHARGEABLE

MATERIALS: Silicone (massager) ABS with Metallic Plating (décor) Nickel-Free Copper (charging port)

MEASUREMENTS:

8.25" x 1.5"/21 cm x 3.75 cm

OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the top button for 3 seconds.
2. Press the bottom button repeatedly until the desired function is reached.
3. To turn product off, repeat step 1.

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2 hours; Run time on high: 70 minutes; Run time on low: 2.5 hours.

CALEXOTICS®

SE-4412-30-3

HYPE™ WAND



FEATURES:

- Ergonomically curved, premium Silicone massager
- 10 functions of vibration, pulsation and escalation
- Flexible shaft moves with you
- Easy push-button control with LED lights
- Security travel lock feature - hold for 3 seconds to turn on or off
- USB rechargeable - charging cord included

10 SILICONE WATER PROOF USB RECHARGEABLE

MATERIALS: Silicone (massager), ABS with PU Cote (controller), ABS with Metallic Plating (décor), Nickel-Free Copper (charging port)

MEASUREMENTS:

4.75" x 1.5"/12 cm x 3.75 cm

OPERATING INSTRUCTIONS:

1. This item comes with a travel lock feature. To turn product on, press and hold the top button for 3 seconds.
2. Press the bottom button repeatedly until the desired function is reached.
3. To turn product off, repeat step 1.

CHARGING INFORMATION:

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months. Complete charge time: 2 hours; Run time on high: 75 minutes; Run time on low: 2.5 hours.